



EZ7252 Volatile Fatty Acids (VFA) & Alkalinity Analyser

Kat. číslo produktu: EZ7252.XXXXXXXXXX
CZK Cena bez DPH: Kontaktujte nás

Online, automatic monitoring of critical process parameters and process efficiency in anaerobic digesters

A new control alternative for anaerobic digestion

Due to the expensive or time-consuming character of most analysis methods for anaerobic processes, industrial digesters are usually not adequately monitored. Developed specifically for monitoring anaerobic digesters, the EZ7200 Series bring the possibility of implementing new control alternatives to typical operating problems in mid to large scale digesters.

Critical parameter monitoring, online and automatic

Anaerobic digesters require monitoring of a specific set of critical parameters in order to obtain optimal production efficiency, compliance and biogas yield. The primary parameter is volatile fatty acids (VFAs), representing the metabolic condition of the anaerobic digester and responding quickly to stress induced changes, combined with alkalinity.

The EZ7200 Series are easy-to-operate online titrators using a unique and robust method for measuring the critical process parameters in one single run, enabling insight as well as full control over the anaerobic process:

- Direct titration with minimum volatilisation
- Continuous monitoring of the anaerobic process
- Enabling higher loading rate for maximum CH₄ production
- Prevention of digester failure due to VFA accumulation
- Easy implementation within a dynamic control strategy
- Easy integration into corporate networks

There are many additional options available. Please contact Hach for more details.

Technické údaje

Alarm:	1 x malfunctioning, 4 x user-configurable, max. 24 VDC/0.5 A, potential free contacts
Analogové výstupy:	Active 4 - 20 mA max. 500 Ohm load, standard 1, max. 8 (option)
Certifikace:	CE compliant / ETL certified
Demineralised water:	N.A.
Digitální výstupy:	Optional: Modbus (TCP/IP, RS485)

Doba cyklu :	10 - 15 minutes
Earth connection:	Dry and clean earth pole with low impedance (< 1 Ohm) using an earth cable of > 2.5 mm ²
Hmotnost:	25 kg
Instrument air:	Dry and oil free according to ISA-S7.0.01-1996 quality standard for instrument air
Interference :	Phosphates and similar dissociating ions and non-fatty acids which on acidification from undissociated acids may cause interference. Sulphide may deteriorate some types of pH electrodes. Fats, oil, proteins, surfactants and tar.
Jaký je obsah balení:	EZ7252 VFA & Alkalinity Analyser, Instruction Manual, 1 x Double Bit Door Key, 1 x Mounting Brackets, 1 x pH Electrode, Routine S7 Connection, 2 x empty 10L Reagent Containers with Fittings (NaOH & H ₂ SO ₄ Solution) and 1 x empty 2.5L Reagent Container with Fittings (Anti-foam Solution)
Kalibrace:	Automatic; frequency freely programmable
Materiál:	Hinged part: Thermoform ABS, door: PMMA
	Wall section: Galvanised steel, powder coated
Metoda:	Titrimetric
Metoda měření:	Acid-base titration
Mez detekce:	≤ 10 mg/L
Napájení:	100 - 240 VAC, 50/60 Hz
	Max. power consumption: 120 VA
Odtok:	Atmospheric pressure, vented, min. Ø 32 mm
Okolní teplota:	10 - 30 °C ±4 °C deviation at 5 - 95% relative humidity (non-condensing)
Parametr:	Volatile fatty acids (VFAs), total alkalinity
Počet proudů vzorku:	1, 2, or 4
Požadavky na vzorek:	Maximum particle size 500 µm, < 0.1 g/L
	Most applications require the use of an EZ9130 sampling/filtration system.
Přesnost:	Better than 3% full scale range for standard test solutions
Průtoková rychlost:	100 - 300 mL/min
Reagent Requirements:	Keep between 10 - 30 °C
Rinsing:	With tap water
Rozměry (V x Š x H):	690 mm x 465 mm x 330 mm
Rozsah měření:	VFAs 100 - 5000 mg/L as acetate equivalent;
	Alkalinity, total and Alkalinity, partial 250 - 5000 mg/L as CaCO ₃
Teplota vzorku:	10 - 30 °C
Tlak vzorku:	By external overflow vessel
Třída ochrany:	Analyser cabinet: IP44 / Panel PC: IP65
Validation:	Automatic; frequency freely programmable
Záruka:	24 měsíců

Jaký je obsah balení

EZ7252 VFA & Alkalinity Analyser, Instruction Manual, 1 x Double Bit Door Key, 1 x Mounting Brackets, 1 x pH Electrode, Routine S7 Connection, 2 x empty 10L Reagent Containers with Fittings (NaOH & H₂SO₄ Solution) and 1 x empty 2.5L Reagent Container with Fittings (Anti-foam Solution)